

WARNING

BEFORE INSTALLATION

- DISCONNECT THE BATTERY FROM THE ENGINE.
- MAKE SURE THE ENGINE CAN'T OPERATE DURING INSTALL.
- FOLLOW ALL ENGINE SAFETY WARNINGS.
- READ THE FOLLOWING INSTALLATION INSTRUCTIONS.

PLEASE READ INSTRUCTIONS

BEFORE INSTALLING

A visual inspection is recommended for this product before installation in case of damage during shipment. It is your responsibility to have a qualified person to install this unit.

Toggle Switch

This Toggle Switch is a momentary switch that allows for the activation of the PASV killing the engine. Once the switch is let go the PASV will reset itself within 12-15 seconds.

The toggle switch can either be used independently or wired along in combination with various available auto-reset switches sold by Mitey Titan Industries Inc. The wiring diagram below depicts the toggle switch supplied without the speed switch harness.

The toggle switches that come pre-built into other speed switch options will have their own wiring diagram in the kit ordered. Please refer to the documentation that is included in your kit based on your order.

⚠ CAUTION

- Make sure the toggle switch is in a location that a user can access readily when required.
- Please make sure to install the toggle switch in a dry location and free from heavy moisture.
- Before doing any of the wiring make sure to turn off the power source and stop the engine.

WIRING DIAGRAM FOR PASV TOGGLE SWITCH

